

BUMPER BALLS

INSTRUCTIONS

- 1- SLIDE BUMPER BALL DOWN THE SHAFT OF THE DRILL TO WITHIN 6-8" OF END**
- 2- INSERT DRILL BIT INTO WALL THROUGH OPENING**
- 3- FLEX DRILL BIT SHAFT AGAINST WALL AND START DRILLING!**

NOTE: TO ENSURE PROPER USE OF PRODUCT, ONLY USE FLEXIBLE DRILLS. USE OF NON-FLEXIBLE DRILL MAY RESULT IN DAMAGE TO WALLS



FEATURES: 2 BUMPER BALLS (1 3/4" AND 2 1/4")

***UTILIZE CORRECT SIZE FOR WALL CAVITY (2X4, 2X3 WOOD WALLS)**